

Meguiar's
MIRROR
GLAZE

SoloTM
ONE LIQUID SYSTEM

CUT & POLISH CREAM

86

- Simple, one liquid system for both compounding & polishing
- Delivers revolutionary, swirl-free results
- Safe, VOC compliant formula

**ADVANCED UNIGRITTM
TECHNOLOGY**

CAUTION: Eye & skin
irritant. See back label.

- Use with Solo System buffing pads for best results
- Specifically designed for paint and body shops
- Advanced UnigritTM Technology delivers level cutting and swirl-free polishing
- PAINTABLE: Safe for use in paint shop environment

METHOD OF APPLICATION: For use with rotary buffer.

(NOTE: When using a rotary buffer, be sure you are familiar with its proper use. *)

DIRECTIONS: Shake well. Work one section at a time. Always work on a cool, properly cured, paint surface.

NOTE: To properly prepare the surface for the Solo System, use 1500 grit (or finer) DA dry sanding disks or 2000 grit (or finer) wet sanding paper by hand.

ONE LIQUID SYSTEM

STEP 1: DEFECT REMOVAL: Set rotary buffer to approximately 1800-2000 RPM's. Choose appropriate Solo System buffing pad. To prime new or dry pads, mist on M34 Final Inspection. Apply Cut & Polish Cream directly to properly cured paint surface, and begin working in a 2' x 2' area with overlapping passes. Continue working until defects and sanding marks are removed. Clean pads frequently.

STEP 2: FINAL POLISHING: Set rotary buffer to approximately 1400-1800 RPM's. Choose appropriate Solo System foam buffing pad. To prime new or dry pads, mist on M34 Final Inspection. Apply Cut & Polish Cream directly to paint finish and begin working in a 2' x 2' area with overlapping passes. Continue working until swirl-free finish appears. Wipe remaining residue with a Meguiar's microfiber towel. Clean pads frequently.

Optional: For extreme gloss, follow with a D.A. Polisher application of M80 Speed Glaze or your favorite Meguiar's polish with a Meguiar's foam pad.

CAUTION: Possible eye & skin irritant. **IN CASE OF EYE CONTACT**, rinse gently & thoroughly with lukewarm water. If irritation persists, seek medical attention. **UPON SKIN CONTACT**, wash with soap & water. **KEEP OUT OF REACH OF CHILDREN. FOR PROFESSIONAL USE ONLY. CHEMTREC EMERGENCY PHONE NUMBER: (800) 424-9300.**

Made in USA

VSLM86

©Meguiar's, Inc.
Irvine, CA 92614
meguiars.com
CarCrazyCentral.com
Where the Car Hobby ClicksTM

Meguiar's Holland BV
Postbus 1047
3300BA Dordrecht, Holland
+31 78 621 0268
www.meguiarseurope.nl

*
Rx
HOTLINE
1-800-347-5700
For free, expert car care advice

Serious Car Care For
CAR
Crazy
People!