

LIGHT

EXTRA HEAVY CUT



# Compound

- The next evolution of heavy-cutting high-gloss compounds
- Quickly removes 1,200 grit or finer sanding marks
- Easy wipe-off, virtually zero dust or sling with Rotary or DA
- SHOW CAR RESULTS WHEN PAIRED WITH M210 ULTRA PRO FINISHING POLISH

**CAUTION.** MAY IRRITATE NOSE AND THROAT. Read carefully other cautions on the side panel.

# **ULTRA PRO SPEED COMPOUND**

Engineered for body shop safe fast cutting with easy wipe-off and virtually no dusting.

## METHOD OF APPLICATION:







TIPS: To achieve swirl free finish, clean pad frequently and apply moderate pressure on initial passes, reducing pressure gradually with final passes. Best when followed with M210 Ultra Pro Finishing Polish.

**DIRECTIONS: SHAKE WELL.** Always work on a cool, properly cured paint surface. Prime new or dry pads by misting on M34 Final Inspection.

- 1. ROTARY: Set buffer to approximately 1200-1800 RPMs and apply product directly to the paint surface. Use with Meguiar's® wool or Soft Buff™ Pads and begin working in a 2' x 2' area with overlapping passes. Buff area using light to medium pressure. Reduce pressure when compound begins to dry.
- DA Polisher: Apply directly to appropriate Meguiar's" Soft Buff" DA Foam Disc. Set machine to 4-5 and begin working in a 2' x 2' area with overlapping passes. Apply moderate pressure on initial 2-3 passes followed with light pressure for following two passes.
- 2. Wipe remaining residue with a Meguiar's microfiber towel. Inspect finish with proper lighting. Continue working until defects or sanding marks are removed.

PRECAUTIONS: Avoid breathing dust, vapors, mist or spray. Use only with adequate ventilation. Do

not swallow. Wash thoroughly after handling.

#### KEEP OUT OF REACH OF CHILDREN.

FIRST AID INFORMATION: Inhalation: Remove person to fresh air. If symptoms persist, get medical attention. Skin Contact: Wash skin with soap and water. If symptoms persist, get medical attention. If Swallowed: Do not induce vomiting. Rinse mouth. If you feel unwell, get medical

CONTAINS: Water (7732-18-5); Aluminium Oxide (1344-28-1); MEDIUM ALIPHATIC SOLVENT NAPHTHA (64742-88-7); GLYCERIN (56-81-5); HYDROTREATED HEAVY NAPHTHA (PETROLEUM) (64742-48-9); HYDROTREATED LIGHT PETROLEUM DISTILLATES (64742-47-8); White mineral oil of the control of the con (petroleum) (8042-47-5); Castor oil (8001-79-4); Triethanolamine (102-71-6)

# Reflect Your Passion"

### VSLM110

© Meguiar's Inc. Irvine, CA 92614 uiars.com

3 Lamport Court, Heartlands Daventry, Northants, NNII 8UF +44 870 241 6696 meguiars.com/international